


WORKTOPS



OFFER RANGE IN 4 STEPS



1st STEP: CHOOSE YOUR PROFILE



STANDARD:





- POSTFORMING
- PREFOLDING
- EDGE BANDING



ON DEMAND - STEPFORMING:

- Z
- R

EDGE BANDING, RADIUS OR STEP?



Z



CODICE	SP Truc	C M	W	DIM 'D'	H bordo
T01	55	28	14		58
T02	53	28	12		58
T03	55	25	8	bordo DUC	52
T04	53	25	8	bordo DUC	74
T05	53	25	42		74
T06	53	25	38		71

2nd STEP: CHOOSE THE DECOR AND THE SURFACE...



3rd STEP: CHOOSE THE BOARD

STANDARD:

P2 E1

MR E1

ON DEMAND:

MDF

P2 CARB 2

MR CARB 2


4th STEP: CHOOSE THE DIMENSION



PROFILI	DIMENSIONI		
	HEIGHT	WIDTH	THICKNESS
POSTFORMING PREFOLDING EDGE BANDING	3050 / 4200 3660*	600 / 900 / 1200 + others on demand	18 / 28 / 38
R	4200	600 / 900 / 1200 + others on demand	50
Z	4200	600 / 900 / 1200 + others on demand	38 / 50 / 58

*only Oceania Collection


...which size do you need?




AND THE TRASPORT?

TRUCK:
IMBST13

CONTAINER:
IMBST23



Maximum weight: 24 000 kg
In measure 4200x600x38 mm
the maximum load: 320 pcs



In measure 3660x600x38 mm
(perfect measure for the container)
the maximum load is 396 pcs
In measure 4200x600x38 mm the
maximum load is 240 pcs

WE WILL SEND YOU THE DATA SHEETS.



BIJELJINA

EUROSAG DOO
Stefana Dežanskog 242A
76.300 Bijeljina, BiH

TEL: +387 55 243 598
Mail: eurosag@yahoo.com

ISTO NOVO SARAJEVO

EUROSAG DOO
Spasovdanska 19B
71.123 Istočno Novo Sarajevo, BiH

TEL: +387 57 344 335
Mail: eurosag@yahoo.com